



Tools required: Curved Nail Scissors and Solvent Free Glue.



Step - 1 Cut out the center and leave a small (2mm approx.) shelf / lip.



Step - 2 Carefully apply a small bead of SOLVENT FREE glue to the inner edge of the shelf / lip. Keep the glue 1mm away from the outer ring.



Step 3 - Seating the new dial face. Line up the 50 MPH with the 80 KMH.



Dial fitted and back in the car.