

## Fitting Guidelines For C1699 Conversion dial for BMW K1600



Using a scalpel carefully cut away centre of original dial face leaving a 2mm shoulder around the edge. Make sure none of original dial obscures back lighting of new dial.



Carefully apply very small dots of **solvent free** glue to shoulder around edge and centre of the remaining dial.



Take care not get glue on the face of the new dial.



Fit new dial in position and leave to dry.