

C1820 Honda HR-V Fitting Instructions



Step 1: Cut the centre of the dial, leaving a jagged shelf as shown in the pictures above. We recommend aiming to have each point of the shelf be between the small outer km/h numbers on our dial. (See below)



Step 2: Insert the new dial into position on the jagged shelf

Step 3: With the new dial in place, light up the dial from behind to make sure the numbers all illuminate properly and are not blocked by the jagged shelf. Trim the shelf where necessary.



Step 4: Apply small dots of **SOLVENT FREE** glue as shown in the picture above, then place the new dial into position and allow time to dry. The glue must be solvent free.

